






ALCOLOCK™ V3 Technical Note

Changing engine run condition from “FMS + ign” to “Level + ign”



1. Power on V3.
2. Press the left button for two seconds to select the Menu. You will see the *Dates* menu option.
3. Press the left button again six times to scroll through the menu options till you reach *System Maintenance* option.
4. Press the right button once to *Select* the *System Maintenance* option.
Note. You can go back to the previous menu item by keeping the right button pressed for two seconds.
5. Enter the 4 digit System Code (see note below). Use the right button to increment the numbers and the left button to skip to the next digit.
6. Press the right button to *Select* the code you entered.
7. You will see the *Diagnostic* menu option. Press right button to select it.
8. Press the left button two times to scroll through the menu options till you reach *Vehicle Status*.
9. Press the right button to switch between the available options and choose *Level + ign*.
10. Keep the right button pressed to return to the Diagnostic menu and again to exit. This re-initializes V3 with the new selection.

Note. The 4 digit System Code is dynamically generated every day. To get the latest code, use your user name and password to log on to

<http://lvecodealerservice.fr.felcomcorp.com>.

