

Available through:

CANADA Alcohol Countermeasure Systems Corp
+1 416 619 3500
acs-corp.com

COLOMBIA ALCOLOCK Colombia
+57 1 927 8342
alcolock.co

FRANCE ALCOLOCK France
+ 33 4 42 16 60 10
alcolockfrance.fr

HONG KONG Alcohol Countermeasure Systems (HK) Limited
+852 2824 8731
acs-hongkong.com

SWEDEN ALCOLOCK Sverige
+46 8 776 78 00
alcolock.se

UNITED KINGDOM ALCOLOCK UK
+44 78 9166 7047
alcolock.co.uk

UNITED STATES Alcohol Countermeasure Systems, Inc
+1 866 700 9300
alcolockusa.com

Quality management certifications



Warranty

ALCOSIM is warranted to be free from defects in workmanship and material for one year from the date of purchase. Only qualified technicians should perform maintenance on the ALCOSIM.

ACS, ALCOHOL COUNTERMEASURE SYSTEMS, ALCOLOCK, ALCOSIM and the "Molly" are trademarks of Alcohol Countermeasure Systems (International) Inc. and are used under license.

ALCOSIM™

Breath Alcohol Simulator



20181023

Easy and accurate calibration

Easy to use

Once the green light indicates that ALCOSIM is at operating temperature, simply breathe into the inlet hose to produce an air-alcohol sample. The breath alcohol testing instrument compares this sample to the value of the chosen reference solution.

Quality construction

Medical grade plastic and stainless steel provide chemical resistance and anti-corrosion, while extensive internal sealing provides leak resistance. ALCOSIM is built for life time use.

Certified reference material

Alcohol Reference Solution (ARS) is available upon request.

Your safety, our promise

ISO/IEC 17025, ISO 17034, ISO 9001, ISO 14001 and IATF 16949 certified, ACS ensures high quality design and manufacturing of all products and services while balancing our respect for the environment. Our commitment to safety, quality and customer service defines our industry leadership.

ALCOSIM is the easy and accurate way to calibrate or check-calibrate breath-alcohol testing instruments. Carefully maintaining an alcohol reference solution, ALCOSIM produces an air-alcohol sample of precise concentration.

How it works

The standard reference solution, an ethyl-alcohol concentration, is used to produce an air sample with an ethanol concentration. This sample is equivalent to the calibration set point of the breath-alcohol testing instrument.

Equipped with a reference thermometer, ALCOSIM maintains the reference solution at mouth temperature ($+34\text{ }^{\circ}\text{C} \pm 0.02\text{ }^{\circ}\text{C}$) to simulate the density, composition and temperature of a human breath sample.



Liquid level
500 mL



Inlet tube diameter
6.4 mm



Outlet tube diameter
6.4 mm



Time to ready
< 12 minutes



Recycle time
< 5 seconds



Accuracy
 $\pm 0.02\text{ }^{\circ}\text{C}$



Display
Graphic LCD



Operating temperature
 $+5\text{ }^{\circ}\text{C}$ to $+40\text{ }^{\circ}\text{C}$



Operating voltage
100 or 240 volt



Dimensions
227 mm x 130 mm



Weight
560 grams